

Accompanying Instructions for Mounting Shadow
retractable roll screen on Inswing Door, face mount.
(Figure A)

Tools:

- tape measure
- hack saw
- drill
- #5 and #6 Robertson screwdrivers and bits
- 1/8", 7/64", and 5/32" drills.

The sill extender, housing, and tracks must all lie on the same plane on the brick mould or other exterior moulding/structure. Use one of the tracks as a straight edge to achieve proper alignment of the sill extender.

Maintain the position of the sill extender while drilling 1/8" pilot holes (on the same mounting groove) through the sill extender and sill. Attach sill extender with the (4) 1" stainless screws provided.

Before inserting tracks onto handle/housing, be sure the appropriate 3/8" screw has been removed from the end cap, this ensures the track guide can be seated properly within the track: when assembly is complete, open the unit halfway a few times to test for proper function.

When mounting the assembled unit, locate 1/8" drill into existing mounting hole for #2 and drill through sill extender: for #5 and #6, locate 1/8" drill on mounting groove in track, then drill through extender. Procedures 1,2,5, and 6 take 5/8" flat head screws. For procedure 3 and 4, drill through both walls of the track with a 5/32" bit on the mounting groove 1/4" from the end, then fasten with a 1" screw provided.

The handle and striker plate utilize 3/8" screws, while the magnet uses the white 3/4" screws. When the striker plate is attached, place the magnet on it and close the door to locate its position on the brick mould.