



Accompanying Instructions for Mounting Shadow retractable roll screen on Outswing door, inside mount.
(Figure C)

Tools:

- Tape measure
- hack saw
- drill
- #5 and #6 Robertson screwdrivers and bits
- 1/8", 7/64", and 11/64" drills

The track mount, housing, and tracks must all lie on the same plane.

Transfer the line from the sill (1" in) to the top of the door frame so the unit will be mounted along the same plane.

Before inserting tracks onto handle/housing, be sure the appropriate 3/8" screw has been removed from the end cap, this ensures the track guide can be seated properly within the track: when assembly is complete, open the unit halfway a few times to test for proper function.

When mounting the assembled unit, locate by feel the 1/8" drill on the mounting groove inside the track. Drilling for the pilot hole and fastening the mounting screw should be done together before progressing to the next number in the order. The tracks take (5) 5/8" flat head screws.

The handle and magnet utilize 3/8" screws, while the striker plate uses 5/8" screws. When the magnet is attached, place the striker plate on it and close the door to locate its position on the framing.